



## Zehnder Ribbon Electric











All dimensions shown are in millimetres

All steel construction: 40mm x 30mm D-shaped outer frame

70mm x 8mm inner tubes

Connections: 1.2m long flying lead (2 core)

\* does not include immersion heater

Model	Height* ± 2mm	<b>Width</b> ± 2mm	Finish	Output Watts	<b>Weight</b> kg
RB-130-050/GF RB-160-050/GF RB-180-050/GF	1266 1567 1823	500 500 500	painted painted painted	500 600 750	14.5 17.5 20.2
RBC-130-050/GF RBC-160-050/GF RBC-180-050/GF	1266 1567 1823	500 500 500	chrome chrome chrome	300 300 500	14.6 17.5 20.5
					Issue 1.0





## Zehnder Ribbon Electric



## **Tools & Material Required** Component Key Qty Tape measure Α Boss 4 Screwdriver - crosshead В Wall Plug 4 **Pliers** C **Bracket** 4 Electric drill D Screw, 6mm dia x 50mm 4 Masonry drill bit Ε Washer Spirit level **Grub Screw** Stepladder (for taller radiators) Allen Key

## **Assembly Instructions**

Screw bosses (A) to studs on the back of the radiator.

Accurately mark out bracket holes on wall using spirit level, to dimensions as shown on Technical Data Sheet.

Drill four holes to a minimum depth of 65mm & insert wall plugs (B).


Attach brackets (C) to wall with screws (D) & washers (E).

Hang radiator onto wall by inserting bosses (A) into brackets (C).

Tighten grub screws (F) with Allen key (G).

Electric radiators should be fitted only by a qualified electrician and must be earthed and connected to a cable outlet in the bathroom in accordance with I.E.E. wiring regulations. The electrical connection should be made to a '5 amp fused fixed spur' located outside the bathroom.

Note: for maintenance purposes, cable outlets must remain accessible and cables must not be buried directly into walls.







Issue 1.0